



KTM 790 DUKE / 890 R

SPINDLE SLIDERS

FRONT

Installation Instructions

KIT CONTENTS



LEFT SIDE



RIGHT SIDE



Installation Instructions



**1. Remove the OEM bolt.
Slide in the rod.
Put LEFT bobbin on first.**



2. Put screw in, tighten.

Installation Instructions



1. Place bolt onto bobbin, tighten to 6Nm.



2. Place stickers. 3. Go ride!



IMPORTANT



It is recommended that periodic inspections are made to ensure that all bolts are tightend.

Should the bike be involved in an accident a thorough inspection should be made and any components that have taken an impact, no matter how small, be replaced.

The manufacturer or supplier cannot be held responsible for products that are incorrectly mounted or inappropriately used.

It is recommended to check all connections regularly for tightness of fit.

Ensure all electrics including indicators, tail light, brake light and licence plate light lights are working correctly before riding the motorcycle.

**NOW YOU ARE READY...
TO ROCK THE STREETS!**

BAGOROSPERFORMANCE.COM